



Setup: Install AA batteries and sync your controller to your Xbox.

On/Off:

To turn the mods on press the custom button on the back (LED will flash once)

To turn the mods off hold down the button until the LED light flashes off.

Changing Modes:

Pressing the button on the back will move you to the next mode. Holding down the LT and pressing the button will move you to the previous mode. The LED will flash the number for which mode it is in.

MODES

- | | | | |
|-----|---|-----|------------------------------|
| 1: | 3 Round Burst 8/sps | 15: | Drop Shot / Stand |
| 2: | 5 Round Burst 12/sps | 16: | Drop Shot / Lay |
| 3: | RF 6.5/sps Gears of War - Hammerburst | 17: | Drop Shot / Auto Aim / Stand |
| 4: | RF 7.35/sps COD & BattleField: MK-14, Sniper | 18: | Jump Shot - Autos |
| 5: | RF 8.33/sps Gears of War - Pistols | 19: | Gunny Hop RF 8/sps |
| 6: | RF 9.62/sps COD & BattleField: Pistols | 20: | Dual Akimbo RF 8/sps |
| 7: | RF 12/sps All Games | 21: | Dual Akimbo RF 12/sps |
| 8: | RF 14/sps COD & BattleField: Semi-Auto Rifles | 22: | Wild Bill Akimbo 8/sps |
| 9: | RF 16/sps GTA / Red Dead / COD / Left 4 Dead | 23: | Quickscope RT |
| 10: | RF 20/sps Halo Series | 24: | Quickscope LT |
| 11: | SMG/LMG Burst | 25: | Auto Aim Lock Zombies |
| 12: | Quick Auto Aim RF 10/sps | 26: | Juju Hop |
| 13: | Crackhead Bob Auto Aim | 27: | Juju Hop RF 10/sps |
| 14: | LT Aim RF 8/sps | 28: | Juju Voodoo |

(SPS = Shots per second. Can vary with different games.) (RF = Rapid Fire)