

PREMIUM CONTROLLER2

**THE CONTROLLER MUST BE CALIBRATED BEFORE USING RAPID FIRE
AND AFTER THE BATTERIES ARE REMOVED**

Calibrating:

- 1) Remove the battery.**
 - 2) Hold down the button on the back of the controller**
 - 3) With the button still held down insert the battery.**
 - 4) Power on the controller.**
 - 5) Let go of the button . Must be done after powering the controller on. (LED flashes 3 times)**
 - 6) Push the button to turn on rapid fire and press the right trigger while in Mode 1.**
 - 7) Sync your controller with your xbox by pressing the sync buttons on both.**
- Your controller will now be calibrated.**
(If the controller fires on its own repeat steps 1-6)

Basic Operating Instructions:

Changing Modes

Pressing the button on the back will move you to the next mode. Holding down the LT and pressing the button will move you to the previous mode. The 4th LED will flash the number for which mode it is in.

On/Off

To turn the mod off, hold down the button until the LED 4 light goes out. Tapping the button will turn the mod back on and bring it back into the mode it was in before it was turned off.

Modes

- 1. Burst mode 1**
- 2. Burst mode 2**
- 3. Burst mode 3**
- 4. RF 5/sps**
- 5. RF 8/sps**
- 6. RF 10/sps Cap Buster**
- 7. RF 15/sps**
- 8. RF 20/sps**
- 9. RF 40/sps**
- 10. RF 80/sps**
- 11. SMG/LMB Burst**

12. Aim Kneel
13. Caffeine Freak
14. Quick Aim
15. Crackhead Bob
16. Drop Shot RF 10/sps
17. Jump Shot
18. Dual / Akimbo RF 7/sps
19. Dual / Akimbo RF 11/sps
20. Quickscope RT
21. Zombie Auto Aim RF 12/sps
22. Juuju Hop RF 10/sps
23. Juuju voodoo LT
24. Halo Ultimate RF
25. Halo Auto
26. RF anti recoil
27. Ultimate Quickscope LT

(SPS = Shots per second. Can vary with different games.)